

INSTALLATION GUIDELINES

BSADA with Off Module Conversion

IMPORTANT: BSADA Overhead with Off-Module Conversation Kit can only be installed on B3 fabric tile. Tiles below the Overhead can be Fabric, HP Laminate and Accessory Tile. However, the tile the Overhead is hanging on must be Fabric.

STEP 1: Remove the panel Top trim

STEP 2: Hang the BSADA Overhead with Off-Module Conversation Kit onto the top edge of fabric tile.

STEP 3: Ensure that the Rear Hanging Bracket is fully engaged with the Fabric Tile.

STEP 4: Insert the Bottom Off-Module Bracket into the gap between panel tiles.

STEP 5: Rotate the Bracket up until it is completely engaged along the full length of the Overhead Storage Cabinet bottom.

STEP 6: Drive in the Bracket screws to prevent the bracket from disengaging.

STEP 7: Replace the panel Top trim.

