

INSTALLATION GUIDELINES

Aluminum Framed Wellness Screens Installation Guide • L2AFD

The kit consists of two vertical wall mounting brackets, anodized aluminum frame and clear acrylic. Both brackets are furnished with horizontal pins which allow the brackets to slide in and out of the frame by 1/2" per side, thus adding some degree of dimensional tolerance and installation flexibility.

The brackets add about 0.300" to overall width of the frame (0.150" per side) so, for example, 36" frame will fit between walls 36.300" - 37.500" apart.

STEP 1: Measure and mark the vertical and horizontal location of the frames into the frame. If you are installing the frame at certain distance above the counter you can place improvised spacers on the counter for the frame to reference during installation.

STEP 2: Insert both wall mounting brackets into the frame

STEP 3: Slide the frame into its final, desired position.

STEP 4: Trace oblong holes in the bracket onto the wall to mark the location of wall hardware of your choice.

Note: Because of the wide variety of wall/partition materials Global Contract can not supply wall mounting hardware specific to your application.

4 wall anchors are required for each side

STEP 5: Install the wall anchors of your choice, slide the frame with brackets back between the walls and secure both wall brackets with screws specified by the wall anchor supplier.

Double Sided Adhesive Tape Installation

In some cases client may request to install the frame without drilling into the wall. Each bracket is 33" high and 1.5" wide and provides ample surface bonding area.

Note: Because of a wide variety of wall/partition surface materials Global Contract can not supply adhesive tape precisely for your application. Please consult your local supplier. The bracket surface area is powder coated.

