


PERSONAL TOWER

Item#	Description	Qty	Material
1	Case	1	Steel
2	Divider panel screw	4	Steel
3	Divider panel	1	Steel
4	Top stiffener plug	2	Plastic (PVC)
5	Hanger rod screw	1	Steel
6	Hanger rod	1	Steel
7	Rubber bumper	3	Miscellaneous
8	Storage door	1	Steel
9	Coat door	1	Steel
10	Hinge	4	Steel
11	Hinge screw	16	Steel
12	Lock - Storage door	1	Steel
13	6" Box drawer	2	Steel
14	Divider plate	1	Steel
15	Pencil tray	1	Plastic (PVC)
16	6" Box front (9100 Plus type)	2	Steel
17	Lock - Mid shelf	1	Steel
18	12" File front (9100 Plus type)	2	Steel
19	Screws	16	Steel
20	12" File drawer	2	Steel
21	File bar	2	Steel
22	Bar block	4	Plastic (PVC)
23	6" slide (pair)	2	Steel
24	12" slide (pair)	1	Steel
25	Shelf screw	2	Steel
26	Storage shelf	1	Steel
27	Shelf bracket	2	Plastic (PVC)
28	Mid shelf	1	Steel
29	Leveller	4	Steel



DISASSEMBLY INSTRUCTIONS

A. DISASSEMBLE THE DOORS

Open the storage door (8) and coat door (9)
 Remove hinges (10) and screws (11) and lock - door (12)
 Press the hinge disconnect tab (rear of the hinge)
 and remove the door.

C. DISASSEMBLE THE DRAWERS

Open the 6" drawer (13) remove divider plate (14) pencil tray (15)
 Extend the slides (23) fully, tilt towards centre and lift,
 Tap on the back of the drawer to dislodge, if necessary.
 Open the 12" drawer (20) remove file bar (21) bar block (22)
 Extend the slides (24) fully, tilt towards centre and lift,
 using the screwdriver to release the slide front lock tab .
 Tap on the back of the drawer to dislodge, if necessary.
 Remove screws (19) holding the 6" and 12" drawer front (16) and (18)

B. DISASSEMBLE THE CASE

Remove top stiffener plugs (4)
 Shelves (26) shelf screws (25) shelf support brackets (27) mid shelf (28) and lock (17)
 Remove hanger rod screw (5) and hanger rod (6)
 divider panel screws (2) and divider panel (3)
 Remove rubber bumpers (7)
 Remove levellers (29)

