


roductiv



# MONITOR ARM INSTALLATION GUIDE

## PSMS OVERVIEW (also valid for EVMS/GAMS)




LOADING CAPACITY: 2.2 - 13.2 lbs. per monitor

**SCREEN SIZE: 17"-29"** 

## **PARTS LIST**

#### Components







2. VESA Plate (x1)


#### Parts in the Regular Screw Bag



A. M4 x 9 Screw (x4)



B. M4 x 12 Screw (x4)



C. 4mm Allen Key (x1)



D. 5mm Allen Key (x1)



E. Spacer (x1)




F. Connecting Screw (x1)

#### STEP 1 - REMOVE THE ORIGINAL VESA MOUNT


Loosen the connecting screw.






#### **STEP 2 - INSTALL THE MINI SLIDE**

Insert the Mini Slide.




Tighten the connecting screw.



#### **STEP 3 - VESA PLATE INSTALLATION**

Tighten screws into VESA plate on VESA compliant monitor.





Part A - M4 x 9 screw is the default VESA screw size for most monitors and is designed to be hand-tightened.



Part B - M4 x 12 screw is provided to accommodate monitors requiring longer VESA screws.

# **STEP 4 - MONITOR INSTALLATION**


Slide and lock-in.




Before sliding in, please make sure the knob on the VESA plate is vertical.




Then turn the knob to right to lock and fix the VESA plate





# **STEP 5 - ADJUSTMENT ON THE MINI SLIDE**



# **NOTE: 3 POSITIONS FOR CONNECTION**

